Extraordinary Photoluminescence and Strong Temperature/Angle-Dependent Raman Responses in Few-Layer Phosphorene

Shuang Zhang,^{†,⊥} Jiong Yang,^{†,⊥} Renjing Xu,[†] Fan Wang,[‡] Weifeng Li,[§] Muhammad Ghufran,[†] Yong-Wei Zhang,[§] Zongfu Yu,[∥] Gang Zhang,[§] Qinghua Qin,[†] and Yuerui Lu^{*,†}

[†]Research School of Engineering, College of Engineering and Computer Science, The Australian National University, Canberra, ACT 0200, Australia, [‡]Department of Electronic Materials Engineering, Research School of Physics and Engineering, The Australian National University, Canberra, ACT 0200, Australia, [§]Institute of High Performance Computing, A*STAR, 138632, Singapore, and ^{II} Department of Electrical and Computer Engineering, University of Wisconsin, Madison, Wisconsin 53706, United States. [⊥]S. Zhang and J. Yang contributed equally to this work.

ABSTRACT Phosphorene is a new family member of twodimensional materials. We observed strong and highly layerdependent photoluminescence in few-layer phosphorene (two to five layers). The results confirmed the theoretical prediction that few-layer phosphorene has a direct and layer-sensitive band gap. We also demonstrated that few-layer phosphorene is more sensitive to temperature modulation than graphene and MoS₂ in Raman scattering. The anisotropic Raman response in few-layer phosphorene has enabled us to use an optical method to quickly determine



the crystalline orientation without tunneling electron microscopy or scanning tunneling microscopy. Our results provide much needed experimental information about the band structures and exciton nature in few-layer phosphorene.

KEYWORDS: phosphorene · photoluminescence · two-dimensional · anisotropic · energy gap

wo-dimensional (2D) layered materials, including semimetallic graphene, 1-7semiconducting transition metal dichalcogenides (TMDs),^{8–11} and insulating hexagonal boron nitride (hBN),^{12,13} have been heavily investigated in the past decade. Compared with the gapless graphene, most recently investigated TMD semiconductor MoS₂ has an energy gap in the range 1.3 eV (bulk) to 1.8 eV (monolayer). MoS₂, an indirect band gap material in its bulk form, becomes a direct band gap semiconductor when thinned to a monolayer, enabling significantly enhanced photoluminescence in monolayer MoS₂.^{10,14–16} Black phosphorus (termed phosphorene) has become a new class of 2D layered material, with a predicted layer-dependent band gap ranging from 0.3 eV (bulk) to 1.5 eV (monolayer). $^{\rm 17-22}$ Particularly, few-layer phosphorene with narrow band gaps ranging from mid-infrared to near-infrared wavelengths can fill the

space between the gapless graphene and the comparably large gap TMD semiconductors.^{22–24} The predicted direct band gap nature in few-layer phosphorene will also enable high-performance optoelectronic devices, compared with the indirect band gap behavior in most few-layer TMD semiconductors. However, so far there has been very little experimental data to confirm the theoretical prediction in fewlayer phosphorene.

RESULTS AND DISCUSSION

Here, we report the extraordinarily strong and highly layer-dependent photoluminescence (PL) in few-layer phosphorene, which confirms the predicted direct and layerdependent band gap nature in few-layer phosphorene. Surprisingly, the PL intensity increases exponentially with decreasing layer thickness from five- to two-layer, while the thinner layer phosphorene has less

* Address correspondence to yuerui.lu@anu.edu.au.

Received for review July 16, 2014 and accepted September 4, 2014.

Published online September 04, 2014 10.1021/nn503893j

© 2014 American Chemical Society

VOL.8 • NO.9 • 9590-9596 • 2014





Figure 1. Images and characterization of exfoliated phosphorene. (a) Microscope image of 2L phosphorene. (b) AFM image of 2L phosphorene, with region indicated in the dashed line box in (a). (c) Raman spectrum of 2L phosphorene. (d) Schematic plot of phosphorene layer structure.

volume of materials. Our temperature-dependent Raman spectra measurement showed that few-layer phosphorene is more sensitive to temperature than graphene and MoS₂. The strong anisotropic properties in phosphorene allow for the fast determination of its crystalline orientation by simple Raman microscopy, without the requirements of complicated high-resolution imaging systems, like STM or TEM.

Few-layer phosphorene flakes (Figure 1) were fabricated using mechanical exfoliation techniques onto a Si/SiO₂ chip substrate (275 nm SiO₂), similar to that for graphene and MoS₂.^{7,10,25} The flakes were first identified by optical contrast in a microscope. Regions with different colors correspond to phosphorene flakes with different thicknesses. Figure 1a displays the optical microscope image of a typical thin phosphorene sample (two layers, indicated by "2L") on a Si/SiO₂ substrate. The layer number identification was confirmed by atomic force microscopy (AFM) imaging of the same sample (Figure 1b). More microscope and AFM images of the phosphorene flakes of different thicknesses are shown in Figure S1.

Optical properties in few-layer phosphorene were investigated by micro-Raman spectroscopy and PL spectroscopy. All the Raman and PL spectroscopy measurements were carried out in a confocal microscopy setup, which has a 532 nm solid-state green laser for excitation and a spatial resolution of sub-1 μ m.

Our PL system has two liquid nitrogen cooled detectors (CCD and InGaAs), which can detect photons with wavelengths ranging from 200 to 1650 nm. All the PL spectra in Figure 2a were measured using the InGaAs detector, and all the Raman spectra were measured using the CCD detector. In order to prevent the few-layer phosphorene from reacting with the moisture or other possible reactants from the environment, the samples were put into a microscope-compatible chamber with a slow flow of nitrogen gas. The measured Raman peaks (Figure 1c), at 359, 437, and 466 cm⁻¹ are attributed to the $A_{g'}^1$, B_{2g} , and A_{g}^2 phonon modes in the crystalline few-layer phosphorene flakes, which matched well with the observations in bulk black phosphorus.²⁶

Our measured PL spectra (Figure 2a) in few-layer phosphorus were highly dependent on numbers of layer (two to five layers). Strong PL peaks at 961, 1268, 1413, and 1558 nm were observed in two-, three-, four-, and five-layered phosphorene, respectively, which correspond to energy peaks of 1.29, 0.98, 0.88, and 0.80 eV, respectively. The measured PL peaks are attributed to the nature of excitons, which represent lower bounds on the fundamental band gap values in few-layer phosphorene, respectively. More PL results on various few-layer (2–5L) phosphorene samples are listed in Table S1 in the Supporting Information. Quite consistent PL center wavelength and peak energy

VOL.8 • NO.9 • 9590-9596 • 2014



Figure 2. Photoluminescence (PL) spectra of thin-layer phosphorene. (a) PL spectra of 2L, 3L, 4L, and 5L phosphorene. Note: The tiny oscillation on the PL curve of 3L is due to the limitation error of the InGaAs detector. (b) Energy gap of 2L, 3L, 4L, and 5L phosphorene from experimental PL spectra and theoretical simulation. (c) Layer dependence of PL peak intensity that is normalized by layer number.

were observed from the samples that have the same layer number. The energy position of the measured PL peak increases rapidly as the layer number decreases. This indirectly confirms our theoretical calculation results that the band gap of few-layer phosphorene increases rapidly as the layer number decreases (Figure 2b), due to the quantum confinement effect. In addition, our measured PL energy peaks from 2L to 5L phosphorene align well with the reported one from monolayer phosphorene (1.45 eV),¹⁷ which matches the theoretical prediction.

Normally, few-layer phosphorene degrades in air within hours.²⁷ In our experiments, in order to achieve accurate PL measurements, few-layer phosphorene flakes were quickly identified by optical contrast under an optical microscope. Then the sample was rapidly put into a microscope-compatible chamber with a slow flow of nitrogen gas for sample protection. The sample exposure time in air for optical microscope imaging was minimized to be less than around 15 min. After the PL or Raman characterizations, a guick AFM scanning (less than 30 min) in ambient atmosphere at room temperature was used to confirm the layer number of the phosphorene flake. The total time of optical microscope imaging and AFM in ambient air was minimized to be less than 45 min, within which the few-layer phosphorene samples would not degrade too much. Also, we checked the effectiveness of this nitrogen chamber for preventing possible sample degradation. We measured the optical microscope images and PL spectra of one 5L phosphorene sample, when the sample was just loaded into the nitrogen chamber and after 16 h. By comparison, the measured PL spectra do not change too much (Figure S2).

We calculated the band structures for 1-5 L phosphorene (Figure S3) using DFT calculations with the implementation of the Vienna ab initio simulation package (VASP).²⁸ Hybrid functionals (HSE06)²⁹ were adopted, together with the projector augmented wave method. A vacuum space of at least 20 Å was kept to avoid mirror interactions. The HSE06 approach is well known to have an inaccurate description of the dispersion force and thus a poor estimation of the interlayer distance. Here all the structures were relaxed by using the optimized Becke88 van der Waals (optB88-vdW) functional.²⁹ The first Brillouin zone was sampled with $10 \times 8 \times 1$ Monkhorst–Pack k-meshes for the structure relaxation, and a kinetic energy cutoff of 500 eV was adopted. The lattice constant was relaxed until the change of total energy is less than 0.01 meV and all the forces on each atom are less than 0.01 eV/Å, which are sufficient to obtain relaxed structures.

Few-layer phosphorene has only several atoms in thickness, but the PL intensities from two- to five-layered phosphorene were all stronger than that from the thick (hundreds of micrometers) Si substrate (Figure 2a). This is because of the direct band gap nature in few-layer phosphorene (Figure S3) and the indirect band gap in silicon. Compared with the indirect band gap behavior in few-layer MoS₂,¹⁰ this universal direct band gap nature in few-layer phosphorene grants them great advantages for various optoelectronic applications.

Surprisingly, the PL peak intensity increases dramatically when the layer number decreases, in spite of the reduced amount of material. Like the method used in MoS₂,¹⁰ we can evaluate the luminescence quantum efficiency (η_{PL}) in few-layer phosphorene by comparing the PL peak intensity (I_{PL}) that is normalized



A



Figure 3. Low-temperature Raman spectra of 5L phosphorene. (a) Raman spectra of a 5L phosphorene at temperatures ranging from 20 to -160 °C. (b) Temperature dependence of $A_{gr}^1 B_{2gr}$ and $A_{g}^2 Raman peak positions$.

by layer number. This normalized PL peak intensity (Figure 2c) indirectly reflects the intrinsic luminescence quantum efficiency, $\eta_{\rm PL}$.¹⁰ This indicates that the intrinsic luminescence quantum efficiency is highly dependent on layer number in few-layer phosphorene. As shown in Figure 2c, the intrinsic luminescence quantum efficiency in 2L phosphorene is more than 1 order of magnitude higher than that in 5L phosphorene.

The strong PL in few-layer phosphorene arises from direct electronic transitions with high radiative recombination rate. The internal luminescence guantum efficiency from such direct electronic transitions in few-layer phosphorene can be approximated by $\eta_{\rm PL} \approx k_{\rm rad}/(k_{\rm rad} + k_{\rm defect} + k_{\rm relax})$, where $k_{\rm rad}$, $k_{\rm defect}$, and k_{relax} are respectively rates of radiative recombination, defect trapping, and electron relaxation within the conduction and valence bands, similar to that in MoS_2 ¹⁰ Both k_{rad} and k_{relax} are highly related to the density of states and the band structures.³⁰ This strong layer-dependent internal quantum efficiency can be understood from the layer-dependent band structures in few-layer phosphorene (Figure S3). As layer number increases from monolayer to five-layer, more and more band valleys and band maxima show up within both the conduction and valence bands, respectively. Those emerging valleys (maxima) in the conduction (valence) band will significantly change the density of states distribution for electrons (holes). Especially, those states provided by the valleys or maxima at the off- Γ points will highly enhance the relaxation rates within the conduction or valence bands, leading to lower internal quantum efficiency in 5L phosphorene compared to that in 2L. Our experimental data point toward the rich PL physics in few-layer phosphorene, which calls for further in-depth theoretical and experimental analysis to fully understand carrier dynamics.

Raman spectroscopy is another powerful tool to characterize the structural and electronic properties of few-layer phosphorene.^{31,32} Particularly, a temperaturedependent Raman study for few-layer phosphorene is important to further understand the fine structure and properties of the material, such as atomic bonds, thermal expansion, and thermal conductivity. The temperature dependence of the Raman spectra, measured at temperatures ranging from 20 to −160 °C in a 5L phosphorene, is shown in Figure 3. The decreasing temperature leads to the blue shift of the Raman phonon modes A_{q}^{1} , B_{2q} , and A_{q}^{2} . The measured temperature dependence of the Raman mode frequency shift in few-layer phosphorene can be characterized by a linear equation: $\omega = \omega_0 + \chi T$, where ω_0 is the mode frequency at 0 K and χ is the first-order temperature coefficient. The measured χ values for modes A_{q}^1 , B_{2q} , and A_{α}^2 in the 5L phosphorene are -0.023, -0.018, and -0.023 cm⁻¹/°C, respectively (Figure 3b). The change of Raman shift with temperature is determined by the anharmonic terms in the lattice potential energy, which is related to the anharmonic potential constants, the phonon occupation number, and the thermal expansion of the crystal.³³ These measured χ values in 5L phosphorene are all larger in absolute value than those from both bilayer graphene ($-0.0154 \text{ cm}^{-1}/^{\circ}\text{C}$ for G peak)³¹ and few-layer MoS₂ (-0.0123 and -0.0132 cm⁻¹/°C for A_{1g} and E¹_{2g} modes, respectively).³² This indicates that the phonon frequencies in few-layer phosphorene are more sensitive to temperature modulation than those in graphene and MoS₂, which could be due to the superior mechanical flexibility of phosphorene originating from its unique puckered crystal structure.34

Compared with other 2D materials, phosphorene shows strong anisotropic properties, ^{17,35} allowing for

VOL.8 • NO.9 • 9590-9596 • 2014

JAI



Figure 4. Phosphorene crystalline orientation determination by polarization Raman spectra. (a) Raman spectra of a 15L phosphorene under different polarization angles. (b) Polarization dependence of A_g^1 , B_{2g} , and A_g^2 modes in a 15L phosphorene and the Raman peaks in silicon. (c) Schematic plot showing the vibration directions of A_g^1 , B_{2g} , and A_g^2 Raman modes. (d) Crystalline orientation of the 15L phosphorene flake, determined by angle-dependent Raman measurement.

various unique applications in optoelectronics. Normally, TEM is used to analyze the crystalline orientation of crystals, but the high-energy electrons in TEM are likely to introduce many defects in phosphorene, which can expedite the reaction of phosphorene with moisture and other possible reactants from the environment.²⁷ Thus, it is important to develop optical means to characterize the crystalline properties. It has been recently shown that second-harmonic generation is used to determine the crystalline orientation of MoS₂.³⁶ Both polarized reflection spectroscopy²⁴ and polarized IR spectroscopy²³ are capable of providing simple and nondestructive optical ways to determine the crystalline orientation of phosphorene. Here we further report an alternative and simple optical method based on anisotropic Raman response to determine the crystalline orientation of phosphorene.

We performed linearly polarized Raman measurements to quickly determine the crystalline orientation of a phosphorene flake (15L) (Figure 4). The normally incident laser was in the *z* direction. The polarization angle θ is relative to the 0 degree reference, which can be arbitrarily selected at the beginning. We observed that the Raman intensities of B_{2g} and A²_g modes are significantly dependent on the polarization angle (Figure 4a). The angle-dependent intensities of B_{2q} and A_{α}^2 modes both show an angle period of 180° and are out-of-phase (Figure 4b). The Raman intensity of A_{q}^{1} is less sensitive to the polarization angle (Figure 4b). Our measurement results can be perfectly explained by the vibration directions of these three Raman modes in crystalline black phosphorus.²⁶ Figure 4c shows a schematic of the vibration direction of the phosphorus atoms in the different Raman modes.²⁶ In A_{g}^{2} , B_{2g} , and A_{g}^{1} vibrational modes, the phosphorus atoms oscillate along the x (zigzag), y(armchair), and z (out-of-plane) directions, respectively. When the laser polarization is parallel to the x direction (y direction), the intensity of the A_{α}^{2} mode will reach the maximum (minimum) value, while the intensity of the $B_{2\alpha}$ mode will reach the minimum (maximum) value. Our measurement result (Figure 4b) highly matched this theoretical prediction. On the basis of this polarization-dependent Raman measurement, the crystalline orientation of the 15L phosphorene flake was quickly determined, as indicated in Figure 4d. This technique provides a fast and precise determination of the crystalline orientation, without the need of complicated and high-resolution imaging systems, like STM or TEM. Here, we just considered the incident laser

VOL.8 • NO.9 • 9590-9596 • 2014

polarization and the oscillation direction of the atom vibration. In order to more accurately interpret the polarization dependence of A_{g}^2 , B_{2g} , and A_{g}^1 Raman modes, more factors might need to be considered, such as polarization of the scattering light. Considering this, the polarization dependence of A_{a}^1 is probably intrinsic.

CONCLUSIONS

In conclusion, we observed strong and layer-sensitive PL in two- to five-layered phosphorene. The energy gaps, determined from the PL spectra, are highly dependent on the numbers of layers, which matches well with the theoretical simulation. This PL measurement provides very useful information to study the exciton nature and the electronic structures in fewlayer phosphorene. Our temperature-dependent Raman measurements demonstrated that few-layer phosphorene is more sensitive to temperature modulation than graphene and MoS₂. Also, the highly angle-dependent Raman spectra from a phosphorene flake enabled us to quickly determine the crystalline orientation of the flake without TEM or STM.

EXPERIMENTAL METHODS

The thin-layer phosphorene was transferred onto a SiO₂/Si substrate (275 nm thermal SiO₂) by mechanical exfoliation from bulk black phosphorus single crystals (from Smart-elements), using GEL film (Gel-Pak). Few-layer phosphorene flakes were quickly identified by optical contrast under an optical microscope. Then the sample was rapidly put into a microscopecompatible chamber with a slow flow of nitrogen protection gas, in order to slow the reaction of phosphorene with moisture and other possible reactants from the environment. The sample exposure time in air for optical microscope imaging was minimized to be less than around 15 min. All PL, Raman, and polarization measurements were conducted with a T64000 micro-Raman system equipped with both CCD and InGaAs detectors. For low-temperature Raman measurements, a Linkam THMS 600 liquid nitrogen low-temperature stage was added onto the micro-Raman system. For polarization measurements, we inserted an angle-variable polaroid into the optical path of the micro-Raman system and shifted the polaroid 6 degrees every time and then proceeded 30 times to get a full period of polarization results. To avoid laser-induced sample damage, all Raman and PL spectra were recorded at low power levels P of \sim 100 μ W. Raman measurements used short integration times of ${\sim}10$ s, and PL used longer integration times of ${\sim}60$ s. The nitrogen chamber and low-power laser can effectively protect the sample. After the PL or Raman characterizations, a quick AFM scanning (less than 30 min) was used to confirm the layer number of the phosphorene flake, which was carried out in ambient atmosphere at room temperature with a Bruker Multi-Mode III AFM.

Conflict of Interest: The authors declare no competing financial interest.

Acknowledgment. We would like to thank Prof. Chennupati Jagadish, Prof. Barry Luther-Davies, and Prof. Vincent Craig from The Australian National University, for their facility support. We acknowledge financial support from an ANU Ph.D. student scholarship, Wisconsin Alumni Research Foundation, Australian Research Council, and ANU Major Equipment Committee.

Supporting Information Available: Details of theoretical calculation methods, more experimental PL measurement results, and characterization of the sample protection by nitrogen flow chamber are shown in the Supporting Information. This material is available free of charge via the Internet at http://pubs.acs.org.

REFERENCES AND NOTES

- 1. Ferrari, A. C.; Basko, D. M. Raman Spectroscopy as a Versatile Tool for Studying the Properties of Graphene. *Nat. Nanotechnol.* **2013**, *8*, 235–246.
- Lui, C. H.; Mak, K. F.; Shan, J.; Heinz, T. F. Ultrafast Photoluminescence from Graphene. *Phys. Rev. Lett.* **2010**, *105*, 127404.
- Schwierz, F. Graphene Transistors. Nat. Nanotechnol. 2010, 5, 487–496.

- Geim, A. K.; Novoselov, K. S. The Rise of Graphene. Nat. Mater. 2007, 6, 183–191.
- Zhang, Y.; Tan, Y.-W.; Stormer, H. L.; Kim, P. Experimental Observation of the Quantum Hall Effect and Berry's Phase in Graphene. *Nature* 2005, 438, 201–204.
- Novoselov, K. S.; Geim, A. K.; Morozov, S. V.; Jiang, D.; Zhang, Y.; Dubonos, S. V.; Grigorieva, I. V.; Firsov, A. A. Electric Field Effect in Atomically Thin Carbon Films. *Science* 2004, *306*, 666–669.
- Novoselov, K. S.; Geim, A. K.; Morozov, S. V.; Jiang, D.; Katsnelson, M. I.; Grigorieva, I. V.; Dubonos, S. V.; Firsov, A. A. Two-Dimensional Gas of Massless Dirac Fermions in Graphene. *Nature* **2005**, 438, 197–200.
- Cao, T.; Wang, G.; Han, W.; Ye, H.; Zhu, C.; Shi, J.; Niu, Q.; Tan, P.; Wang, E.; Liu, B.; *et al.* Valley-Selective Circular Dichroism of Monolayer Molybdenum Disulphide. *Nat. Commun.* 2012, *3*, 887.
- Gutiérrez, H. R.; Perea-López, N.; Elías, A. L.; Berkdemir, A.; Wang, B.; Lv, R.; López-Urías, F.; Crespi, V. H.; Terrones, H.; Terrones, M. Extraordinary Room-Temperature Photoluminescence in Triangular WS₂ Monolayers. *Nano Lett.* 2012, *13*, 3447–3454.
- Splendiani, A.; Sun, L.; Zhang, Y.; Li, T.; Kim, J.; Chim, C.-Y.; Galli, G.; Wang, F. Emerging Photoluminescence in Monolayer MoS₂. *Nano Lett.* **2010**, *10*, 1271–1275.
- Radisavljevic, B.; Radenovic, A.; Brivio, J.; Giacometti, V.; Kis, A. Single-Layer MoS₂ Transistors. *Nat. Nanotechnol.* **2011**, 6, 147–150.
- Constantinescu, G.; Kuc, A.; Heine, T. Stacking in Bulk and Bilayer Hexagonal Boron Nitride. *Phys. Rev. Lett.* **2013**, *111*, 036104.
- Xue, J.; Sanchez-Yamagishi, J.; Bulmash, D.; Jacquod, P.; Deshpande, A.; Watanabe, K.; Taniguchi, T.; Jarillo-Herrero, P.; LeRoy, B. J. Scanning Tunnelling Microscopy and Spectroscopy of Ultra-Flat Graphene on Hexagonal Boron Nitride. *Nat. Mater.* 2011, 10, 282–285.
- Mak, K. F.; Lee, C.; Hone, J.; Shan, J.; Heinz, T. F. Atomically Thin MoS₂: A New Direct-Gap Semiconductor. *Phys. Rev. Lett.* **2010**, *105*, 136805.
- Mak, K. F.; He, K.; Shan, J.; Heinz, T. F. Control of Valley Polarization in Monolayer MoS₂ by Optical Helicity. *Nat. Nanotechnol.* **2012**, *7*, 494–498.
- Yin, Z.; Li, H.; Li, H.; Jiang, L.; Shi, Y.; Sun, Y.; Lu, G.; Zhang, Q.; Chen, X.; Zhang, H. Single-Layer MoS₂ Phototransistors. ACS Nano 2011, 6, 74–80.
- Liu, H.; Neal, A. T.; Zhu, Z.; Luo, Z.; Xu, X.; Tománek, D.; Ye, P. D. Phosphorene: An Unexplored 2d Semiconductor with a High Hole Mobility. ACS Nano 2014, 8, 4033–4041.
- Zelisko, M.; Hanlumyuang, Y.; Yang, S.; Liu, Y.; Lei, C.; Li, J.; Ajayan, P. M.; Sharma, P. Anomalous Piezoelectricity in Two-Dimensional Graphene Nitride Nanosheets. *Nat. Commun.* 2014, *5*, 4284.
- Buscema, M.; Groenendijk, D. J.; Blanter, S. I.; Steele, G. A.; van der Zant, H. S. J.; Castellanos-Gomez, A. Fast and Broadband Photoresponse of Few-Layer Black Phosphorus Field-Effect Transistors. *Nano Lett.* **2014**, *14*, 3347–3352.



- Hong, T.; Chamlagain, B.; Lin, W.; Chuang, H.-J.; Pan, M.; Zhou, Z.; Xu, Y. Polarized Photocurrent Response in Black Phosphorus Field-Effect Transistors. *Nanoscale* **2014**, *6*, 8978–8983.
- 21. Fei, R.; Yang, L. Strain-Engineering the Anisotropic Electrical Conductance of Few-Layer Black Phosphorus. *Nano Lett.* **2014**, *14*, 2884–2889.
- 22. Qiao, J.; Kong, X.; Hu, Z.-X.; Yang, F.; Ji, W. High-Mobility Transport Anisotropy and Linear Dichroism in Few-Layer Black Phosphorus. *Nat. Commun.* **2014**, *5*, 4475.
- 23. Xia, F.; Wang, H.; Jia, Y. Rediscovering Black Phosphorus as an Anisotropic Layered Material for Optoelectronics and Electronics. *Nat. Commun.* **2014**, *5*, 4458.
- Li, L.; Yu, Y.; Ye, G. J.; Ge, Q.; Ou, X.; Wu, H.; Feng, D.; Chen, X. H.; Zhang, Y. Black Phosphorus Field-Effect Transistors. *Nat. Nanotechnol.* **2014**, *9*, 372–377.
- Bunch, J. S.; van der Zande, A. M.; Verbridge, S. S.; Frank, I. W.; Tanenbaum, D. M.; Parpia, J. M.; Craighead, H. G.; McEuen, P. L. Electromechanical Resonators from Graphene Sheets. *Science* **2007**, *315*, 490–493.
- Sugai, S.; Shirotani, I. Raman and Infrared Reflection Spectroscopy in Black Phosphorus. *Solid State Commun.* 1985, 53, 753–755.
- Castellanos-Gomez, A.; Vicarelli, L.; Prada, E.; Island, J. O.; Narasimha-Acharya, K. L.; Blanter, S. I.; Groenendijk, D. J.; Buscema, M.; Steele, G. A.; Alvarez, J. V.; *et al.* Isolation and Characterization of Few-Layer Black Phosphorus. *2D Mater.* **2014**, *1*, 025001.
- Kresse, G.; Furthmüller, J. Efficient Iterative Schemes for *ab-Initio* Total-Energy Calculations Using a Plane-Wave Basis Set. *Phys. Rev. B* **1996**, *54*, 11169–11186.
- 29. Heyd, J.; Scuseria, G. E.; Ernzerhof, M. Hybrid Functionals Based on a Screened Coulomb Potential. *J. Chem. Phys.* **2003**, *118*, 8207–8215.
- 30. Dumke, W. P. Spontaneous Radiative Recombination in Semiconductors. *Phys. Rev.* **1957**, *105*, 139–144.
- Calizo, I.; Balandin, A. A.; Bao, W.; Miao, F.; Lau, C. N. Temperature Dependence of the Raman Spectra of Graphene and Graphene Multilayers. *Nano Lett.* 2007, 7, 2645–2649.
- Sahoo, S.; Gaur, A. P. S.; Ahmadi, M.; Guinel, M. J. F.; Katiyar, R. S. Temperature-Dependent Raman Studies and Thermal Conductivity of Few-Layer MoS₂. J. Phys. Chem. C 2013, 117, 9042–9047.
- Postmus, C.; Ferraro, J. R.; Mitra, S. S. Pressure Dependence of Infrared Eigenfrequencies of KCI and KBr. *Phys. Rev.* 1968, 174, 983–987.
- Wei, Q.; Peng, X. Superior Mechanical Flexibility of Phosphorene and Few-Layer Black Phosphorus. *ar-Xiv*:1403.7882, 2014.
- Tran, V.; Soklaski, R.; Liang, Y.; Yang, L. Tunable Band Gap and Anisotropic Optical Response in Few-Layer Black Phosphorus. arXiv:1402.4192, 2014.
- Yin, X.; Ye, Z.; Chenet, D. A.; Ye, Y.; O'Brien, K.; Hone, J. C.; Zhang, X. Edge Nonlinear Optics on a MoS₂ Atomic Monolayer. *Science* 2014, 344, 488–490.



Supporting Information for

Extraordinary Photoluminescence and Strong Temperature/Angle-Dependent Raman Responses in Few-Layer Phosphorene

Shuang Zhang,^{1†} Jiong Yang,^{1†}, Renjing Xu,¹ Fan Wang,² Weifeng Li,³ Muhammad Ghufran,¹

Yong-Wei Zhang,³ Zongfu Yu,⁴ Gang Zhang,³ Qinghua Qin,¹ and Yuerui Lu^{1*}

¹Research School of Engineering, College of Engineering and Computer Science, The Australian National University, Canberra, ACT, 0200, Australia

²Department of Electronic Materials Engineering, Research School of Physics and Engineering, The Australian National University, Canberra, ACT, 0200, Australia

³Institute of High Performance Computing, A*STAR, 138632, Singapore

⁴Department of Electrical and Computer Engineering, University of Wisconsin, Madison, Wisconsin 53706, USA

[†] These authors contributed equally to this work

* To whom correspondence should be addressed. Email: <u>yuerui.lu@anu.edu.au</u>

1. PL measurement data from various few-layer phosphorene samples

The PL spectra of multiple few-layer phosphorene samples were characterized (Table S1). Quite consistent PL center wavelength and peak energy were observed from the samples that have the same layer number.

Samples	No. of layers	PL center wavelength (nm)	Peak energy (eV)
Sample-1	2L	961	1.29
Sample-2	2L	965	1.29
Sample-3	3L	1268	0.98
Sample-4	3L	1264	0.98
Sample-5	4L	1413	0.88
Sample-6	4L	1441	0.86
Sample-7	5L	1558	0.80
Sample-8	5L	1555	0.80
Sample-9	5L	1557	0.80

Table S1: PL measurement data from various few-layer phosphorene samples.

2. Theoretical calculation methods

In the calculations, the number of few-layer phosphorene was considered from 1L to 5L. All the structural optimization and band structure calculations were performed using DFT calculations implemented in the plane wave code Vienna *ab initio* simulation package (VASP).^{1, 2} Hybrid functionals (HSE06)³ were adopted, together with the projector augmented wave method. A vacuum space of at least 20 Å was kept to avoid mirror interactions. The HSE06 approach is well-known to have an inaccurate description of the dispersion force and thus a poor estimation of the interlayer distance. Here all the structures were relaxed by using the optimized Becke88 van der

Waals (optB88-vdW) functional.⁴ The first Brillouin zone was sampled with a $10 \times 8 \times 1$ Monkhorst-Pack k-meshes for the structure relaxation, and a kinetic energy cut off of 500 eV was adopted. The lattice constant was relaxed until the change of total energy is less than 0.01 meV and all the forces on each atom are less than 0.01 eV/Å, which are sufficient to obtain relaxed structures. The relaxed lattice constant for the 1L phosphorene is a = 3.34 Å and b = 4.57 Å, in good agreement with previous study.⁵ Figure S2 (b)-(f) shows the band structures for 1L to 5L phosphorene calculated using HSE06.



Figure S1. Microscope and AFM images of 3L, 4L and 5L phosphorene. (a) Microscope image of 3L and 4L phosphorene. (b) Microscope image of 5L phosphorene. (c)-(e) show the AFM images of 3L, 4L and 5L phosphorene, respectively.

Figure S2. Phosphorene performance before and after nitrogen chamber protection. (a)-(b)

Optical microscope images of a 5L phosphorene in nitrogen chamber protection when it was just loaded in (a) and after 16 hours (b). (c)-(d) Measured PL spectra of the 5L phosphorene in nitrogen chamber protection when it was just loaded in (c) and after 16 hours (d).

Figure S3. Simulated band structures for phosphorene (1-5 layers) based on DFT calculation.

(a) Schematic plot showing the lattice structure of phosphorene. (b)-(f) shows the band structures

for 1L to 5L phosphorene calculated using HSE06.

References

- 1. Kresse, G.; Furthmüller, J. Efficient Iterative Schemes for *Ab-Initio* Total-Energy Calculations Using a Plane-Wave Basis Set. *Phys. Rev. B* **1996**, 54, 11169-11186.
- 2. Kresse, G.; Furthmüller, J. Efficiency of *Ab-Initio* Total Energy Calculations for Metals and Semiconductors Using a Plane-Wave Basis Set. *Comput. Mater. Sci.* **1996**, 6, 15-50.
- 3. Heyd, J.; Scuseria, G. E.; Ernzerhof, M. Hybrid Functionals Based on a Screened Coulomb Potential. *J. Chem. Phys.* **2003**, 118, 8207-8215.
- 4. Becke, A. D. Density-Functional Exchange-Energy Approximation with Correct Asymptotic Behavior. *Phys. Rev. A* **1988**, 38, 3098-3100.
- 5. Liu, H.; Neal, A. T.; Zhu, Z.; Luo, Z.; Xu, X.; Tománek, D.; Ye, P. D. Phosphorene: An Unexplored 2d Semiconductor with a High Hole Mobility. *ACS Nano* **2014**, 8, 4033-4041.